


MODE D'EMPLOI

MOUVEMENT AUTOMATIQUE DIVER

MIYOTA 11 $\frac{1}{2}$ 8215



LES AIGUILLES

- A. Aiguille des heures
- B. Aiguille des minutes
- C. Aiguille des secondes
- D. Date

RÉGLAGE DE L'HEURE

1. Dévissez puis tirez la couronne F en position 3
2. Tournez la couronne pour régler les aiguilles des heures et des minutes
3. Repoussez et revissez la couronne F en position 1

RÉGLAGE DE LA DATE

1. Dévissez puis tirez la couronne F en position 2
2. Tournez la couronne pour régler la date
3. Repoussez et revissez la couronne F en position 1


RÉGLAGE DU RÉHAUT

1. Dévissez la couronne E
2. Tournez la couronne pour régler le réhaut
3. Revissez la couronne E

INSTRUCTIONS FOR USE

AUTOMATIC DIVER MOVEMENT

MIYOTA 11 $\frac{1}{2}$ 8215



HANDS

- A. Hour hand
- B. Minute hand
- C. Second hand
- D. Date

SETTING THE TIME

1. Unscrew and pull the crown F to position 3
2. Turn the crown to set the hour and minute hands
3. Push the crown back and screw it back to position 1

SETTING THE DATE

1. Unscrew and pull the crown F to position 2
2. Turn the crown to set the date
3. Push the crown back and screw it back to position 1

SETTING THE ROTATING BEZEL

1. Unscrew crown E
2. Turn the crown to adjust the bezel ring
3. Screw the crown E back on